

## End Of Life

The following is a description of the steps needed to dismantle the Radio 127 unit and includes guidance on recycling.

### Grey Aluminium Case version

- 1) Remove the four rear Class 10.9 low carbon screws. Recyclable
- 2) Remove the rear aluminium diecast lid. Recyclable
- 3) Remove four hex head screws type Class 10.9 low carbon. Recyclable  
The four nyloc nuts are not recyclable seek appropriate authority or agency for disposal.
- 4) Remove internal electronic component PCB. Hazardous recovery seek appropriate authority or agency for disposal.
- 5) Remove internal aluminium spacer plate. Recyclable
- 6) Front aluminium diecast case. Recyclable

### Black powder coat version

- 1) Remove the four rear Class 10.9 low carbon hex head screws. Reuse/Recycle
- 2) Remove the rear aluminium powder coat plate. Recyclable
- 3) Remove four nyloc nuts. Not recyclable seek appropriate authority or agency for disposal.
- 4) Remove internal electronic component PCB. Hazardous recovery seek appropriate authority or agency for disposal.
- 5) Remove EPDM foam gasket. Recyclable
- 6) Front aluminium aluminium powder coat case. Recyclable